

HOLD ENTRIES



THE HEADING INDICATOR METHOD

- 1. Proceed direct to the holding fix
- 2. Determine the hold's outbound course
- 3. Visualize the outbound course on the DG
- 4. Outbound course sector determines entry type



Non-Standard (Left Turns)

Standard (Right Turns) **Outbound Course Sectors**





OUTBOUND COURSE

Direct entry for both standard and non-standard holds



OUTBOUND COURSE

Parallel entry if standard Direct entry if non-standard